

## Know your product



Forward



Backward



90° Left turn



90° Right turn




1 second pause



Clear the memory



Start the program



USB Charging  
Socket

